

# TLR® Remote Switches

For use with the following series: TLR-1®, TLR-2®, TLR HL®, TLR-1® HP, TLR-1® GAMESPOTTER®, TLR-VIR®

## Battery Door Switches

- Easily replaces standard battery door/switch
- Retains momentary/lock on function of original paddle switch
- Rubber weather cap keeps connector dry when remote is not in use
- All remotes feature rotating quick disconnect plug with O-ring seal

Battery door/switch with integrated remote connector  
#69130



Battery door/switch features a "locked off" position to prevent accidental light actuation  
#69161



## Plug-In Remote Switches

- Must be used in conjunction with battery door switch 69130 or 69161
- All plug-in switches include mounting accessories

Shotgun coil remote switch  
#69134

Long gun remote switch  
#69135



Remote tape switch  
#69132

Battery Door/Switch	#69130
Battery Door/Switch with "Locked Off"	#69161
Shotgun coil remote switch allows for expansion of cord with pump action	#69134
Long gun remote switch attaches to rail forend with included clips	#69135
Remote tape switch fits most right-angle grips and other aftermarket accessories	#69132

