



# PEDAL OPERATED HAND SANITIZER DISPENSING STATION INSTALLATION & INSTRUCTIONS

## INSTALLATION & SETUP



Take dispenser out of the box.



Remove the cap.



Twist cap of handsanitizer counterclockwise to release spout.



Attach cap and ready to use!

## REFILLING DISPENSER



Remove cap.



Take out empty bottle.



Replace or refill bottle and put back in dispenser.



Attach cap.

## REMOVE/REPLACE THE CAP



Twist cap clockwise and pull straight up to remove.



Put cap on top and twist counter-clockwise to secure in place.

## LOCKING THE DISPENSER



Locate the circular metal ring in back.



Attach padlock (lock not included).